



- A. Metal brackets**, to be mounted facing and level to each other.
- B. Cross-shaped Hole**
- C1, C2. Pins**
- D. Spindle**
- E. Round Hole**
- F. Nylon Lock**
- G. Nylon Handle**
- H. Hook**

All mounting hardware is included.

TO INSTALL:

Mount the right and left brackets (A) on the case, measuring the space between each part according to the linear length of the unit to be installed (please see template).

Insert the end of the spindle which has the rectangular shaped pin (C₁) into the cross shaped hole (B) making sure that the arrow is pointing UP. This ensures that the fabric rolls off from the back of the unit. Place the small nylon lock (see figure 1) onto the round pin on the right side of the spindle (C₂), ensuring that the slot side of the lock is toward the roll. The lock has a very thin slot which must be inserted into the corresponding slot in the bracket (A) so that the unit will lock in place. Once the pin and lock have been inserted into the bracket, turn the lock down 45° (see figure 2).

All units come from the factory pre-tensioned. If the unit does not release easily after mounting, simply grasp the installed unit in the center, and give it a one inch turn away from you, toward you again, repeating until you feel the lock give way.

Pull down the curtain and mark the position of the hook for the handle. Secure the hook with the screws provided.

figure 1



figure 2

